

Care and maintenance

- When the fan is not in usage, it should be stored in a dry location.
- Always unplug the fan before cleaning or disassembling.
- Clean the outside surfaces of the fan with a damp cloth and mild detergent - do not allow water to enter.


Technical Specification

Nominal voltage	13 V
Voltage range	12V +/- 3V
Power	8.5 W
Current	653 mA
Airflow	30.4 m ³ / min
Speed setting	(high/med/low)
Blade diameter	16"
Cable	6 m
Height (max. height)	125 cm
Weight (net/gross)	3.93 kg / 4.5 kg

Contact:

Fosera Solarsystems GmbH & Co. KGaA
 Beim Mühlbach 3
 89171 Illerkirchberg
 + 49 (0) 7346 924 69 73
 info@fosera.com

Fosera POWER LINE Standing Fan



With the Fosera Standing Fan a pleasant indoor climate can be achieved, and the life quality significantly improved. In hot and dry areas of the world, solar powered cooling and ventilation substantially increase home comfort.

It is the perfect product extension for our POWER LINE. Mobile standing fans are adequate for focusing the air jet where it is most desired. Following Fosera's plug-and-play philosophy, connect the Standig Fan to the Fosera LSHS or to the Fosera EVO and move it where convenient to enjoy its pleasant breeze.

Please read the safety warnings below carefully before using this product.



Before you start

- Unpack the fan ensuring that all the parts are present and that there are no components left in the box. Also ensure the product is free from all packing materials.
- Do not connect the fan to the Fosera system until it is fully assembled.
- Do not connect the fan to the Fosera system if any of the components, or the cable, appear damaged. In doubt please contact the place of purchase.

Operation

- This product can only be powered by Fosera POWER LINE.
- Connect the fan with the included cable to a Fosera system.
- In order to use the timer function use the 120 min. timer knob on the control panel.
- To adjust the speed of the fan choose one of the 3 buttons on the control panel.



Warnings

- This product is designed to be used inside. Do not use the fan in the rain, near the fire or near other dangerous equipments.
- The power cord should be regularly examined for signs of damage and the appliance is not to be used if the cord is damaged. If the power cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid hazard.
- This appliance is not a toy, please make sure that it is not used by children without assistance or supervision if their physical, sensory or mental capabilities prevent them from using it safely. Children should be supervised to ensure they do not play with the appliance.



Warranty

The Fosera Standing Fan comes up with 1 year warranty. During this period we guarantee that our product is free from defects in material or workmanship. Please contact your dealer or local Fosera sales agent if you experience any problems with the product. Your local dealer will then assess the defect and decide whether the product can be repaired or has to be replaced. Fosera is not responsible for any consequential damage or damage that exceeds the value of the product. A warranty repair does not extend the warranty period. The warranty becomes invalid if the device is used other than intended by the manufacturer. This warranty does not cover failures caused by incorrect installation, set up or unusual use. The warranty is also void in case of repairs by any unauthorized or untrained person.