

# Lamp

---

## User Manual



Please read and follow the instructions carefully!

## Introduction

---

Thank you for your purchasing the fosera Lamp. This system has been developed according to German engineering standards. It has been designed to meet your everyday needs, and has a lifetime of many years upon proper usage.

## Package Content

---

- 1x fosera lamp (A)
- 1x User Manual (B)




(A)




(B)

## Installation

---



Place the Lamp at your desired location using a hook screw. Make sure the cable is not pulled too tightly. If you need to extend a cable please use a cable provided by fosera.



Connect the cable of the fosera lamp to one of the blue sockets of the PSHS, LSHS or Scandle.

## Security Advice

---

- Protect the lamp from rain and direct sunlight. Indoor use only!
- Any repair and change of the fosera products must only be carried out by authorized persons. Otherwise no warranty guaranteed.
- The ideal temperature for the functional capability of all fosera products is between 0° Celsius and 50° Celsius.
- Keep all fosera products in a safe place and make sure they are never damaged. Do not open the products.
- If the cables are damaged make sure that they get repaired and replaced.
- Don't use loads and appliances that are not designed and certified for the system. Only use fosera systems to power the lamp. Only use special fosera cable.

## Technical Data

---

	fosera Lamp 200 BLUE LINE	fosera Lamp 100 BLUE LINE
Lamp Voltage	3,25 V	3,25 V
Lamp Current	480mA	245mA
Nominal Power	1,56 W	0,80 W
Illuminance*	180 lm	90 lm
lm/ W	115	115
Lifespan @ 5h use per day**	27 years	27 years

## Recycling Information

---

Do not throw any of the components into trash when discarding. To help minimizing pollution and to protect the global environment, please recycle. All of the fosera components used for manufacturing the system are recyclable. For more information on the Waste from Electrical and Electronics Equipment (WEEE) regulations, please visit the following webpage:

[http://ec.europa.eu/environment/waste/weee/index\\_en.htm](http://ec.europa.eu/environment/waste/weee/index_en.htm)



## Maintenance

---

Keep the Lamp clean. Make sure that no liquids harm the Lamp.

## Contact

Headquarter

Local Retailer

---

fosera GmbH & Co. KGaA  
Beim Mühlbach 3  
89171 Illerkirchberg  
Germany

Tel: +49 7346 92469 73

Fax: +49 7346 92469 75

e-mail: [info@fosera.com](mailto:info@fosera.com)

Visit our website: [www.fosera.com](http://www.fosera.com)

## Warranties

---

We trust in the quality of our products, if it is used properly and following this instructions in installation, use and maintenance it should give you years of satisfying service.

We guarantee it to be free from defects in material or workmanship for 36 months from date of purchase. On the battery we warrant 24 months.

The warranty becomes invalid if the device is used other than intended by the manufacturer. This warranty does not cover failures caused by wrong installation or set up, unusual use or failure to follow installation and user instructions. The warranty is also void in case of repairs by any unauthorized or untrained person. For further instructions please read the user manual.

fosera has the right to decide whether the product will be repaired or replaced. fosera shall not be responsible for any consequential damage or damage that exceeds the value of the product. A warranty repair does not extend the warranty period.

In case of warranty please use the form below to send the product back or bring it back to the merchant you purchased it from. The purchaser has to arrange transport including the costs to our repair base.

fosera is not liable for any damage incurred in transit.

## Warranty Card

---

Name of the product: .....

Date/Place of purchase: .....

Name and Contact of local retailer: .....

For support please contact your local retailer or our headquarter via [service@fosera.com](mailto:service@fosera.com) for support!